

Necessary tools

Allen key 5 mm

Art.nr.

800897

Instructions

To mount the seat on the seat frame, use an allen key to secure the screws through the seat frame as shown in the picture below. The seat frame can be placed in two different positions on seats with a depth of 39 cm or shallower to allow for leg support brackets that add to the depth of the seat frame.

The number of screws required for assembly varies from 4 to 10 screws depending on the type of seat frame.

